

P2P Networking

Enjoy instant viewing of your cameras without having to know networking.
You can set it up as easy as 1, 2, 3. Use the following steps:



1.

FIND the **QR** code for
your **ICRealtime** device



2.



Open an **ICRealtime** app
SCAN the **QR** code

3.

Enjoy
VIEWING!



For detailed instructions visit [support](#) or the [forum](#)

IC Realtime LLC

3050 N Andrews Avenue Extension
Pompano Beach, FL 33064
(866) 997-9009

www.icrealtime.com

Designs and specifications subject to change without notice. Copyright © 2015 IC Realtime, LLC. All rights reserved.